

Laying of large-format ceramic fully vitrified stoneware units on Calcium Sulphate Floor Screeds

1 Prime the floor screed using Sopro SG 602 Resin Primer Sealer as directed, ensuring the screed is fully sealed by proper film formation.

2 Use Sopro FF 450 Standard Set or Sopro FF 451 Rapid Set Tile Adhesive.

Always use the butter and float method - ensuring 100% adhesive coverage of your large format tile by applying a contact layer of adhesive on the back of the tile.

3 Follow by placement of the tile into a prepared combed adhesive bed using a 10mm serated trowel.

4 Use Sopro DF 10 Designer Grout for tile 1-10mm joints to ensure brilliantly coloured joints with a lasting appeal.



SUBSTRATE

Dry and clean Calcium Sulphate Floor Screed



SUBSTRATE PREPARATION

Sopro SG 602 Primer Sealer



BONDING LAYER AND COMBED BED

Sopro FF 450 Adhesive



or Sopro FF 451 Adhesive



GROUTING

Sopro DF 10® or Sopro Brilliant®

