

## System II

# Laying of large-format ceramic fully vitrified stoneware units on Calcium Sulphate Floor Screeds

**1** Prime the floor screed using Sopro SG 602 Resin Primer Sealer as directed, ensuring the screed is fully sealed by proper film formation.

**2** Use Sopro FF 450 Standard Set or Sopro FF 451 Rapid Set Tile Adhesive.

Always use the butter and float method - ensuring 100% adhesive coverage of your large format tile by applying a contact layer of adhesive on the back of the tile.

**3** Follow by placement of the tile into a prepared combed adhesive bed using a 10mm serated trowel.

**4** Use Sopro DF 10 Designer Grout for tile 1-10mm joints to ensure brilliantly coloured joints with a lasting appeal.



### SUBSTRATE

Dry and clean Calcium Sulphate Floor Screed



### SUBSTRATE PREPARATION

Sopro SG 602 Primer Sealer



### BONDING LAYER AND COMBED BED

Sopro FF 450 Adhesive



or Sopro FF 451 Adhesive



### GROUTING

Sopro DF 10® or Sopro Brilliant®

